


# LIGHT SKY<sup>®</sup>

---

## INSTRUCTION MANUAL

- LED Fresnel
- L7-D48F(6000K)
  - L7-T48F(3000K)



Please read these instruction manual carefully before use

---

FLY DRAGON LIGHTING EQUIPMENT CO., LTD

---

## CHANNEL FUNCTION

CHANNEL	DMX VALUE	%	FUNCTION
1	0-255	0-100	Dimmer
2	0-255	0-100	Dimmer fine
3	Strobe		
	0-9	0-3.53	NO function
	10-49	3.92-19.22	Slow closing,fast opening,slow → fast
	50-89	19.61-34.9	Fast closing,slow opening,slow → fast
	90-119	35.29-46.67	Slow closing,slow open,slow → fast
	120-179	47.06-70.2	Random strobe,slow→fast
	180-249	70.59-97.65	Synchronous strobe,slow→fast
	250-255	98.04-100	NO function
4	0-255	0-100	Zoom