


LIGHT SKY[®]

FLY DRAGON LIGHTING EQUIPMENT CO.,LTD



LIGHT SKY[®]

Tel:0086-20-61828288

Fax:0086-20-61828188 Pc:510800

Web:www.lightsky.com.cn

E-mail: flydragon@lightsky.com.cn

asia@lightsky.com.cn

india@lightsky.com.cn

europa@lightsky.com.cn

latinamerica@lightsky.com.cn

middle-east@lightsky.com.cn

american@lightsky.com.cn

Address: No. 43, Yunfeng Road, Xiuquan Street,
Huadu District, Guangzhou, China



LIGHT SKY[®]



PL1015B

USER MANUAL

Please read these user manual carefully before use

CHANNEL FUNCTION

channel (9CH)

Channel	DMX	Percentage	Function
1	0-255	Dimmer	
2	0-255	Shutter	
3	0-255	Red 、 Red-1	
4	0-255	Green 、 Green-1	
5	0-255	Blue 、 Blue-1	
6	0-255	White 、 White-1	
7	0-255	Macro	
8	0-255	Effect	
	0-5	NO Function	
	6-10	Effect1	
	11-15	Effect2	
	16-20	Effect3	
	21-25	Effect4	
	26-30	Effect5	
	31-35	Effect6	
	36-40	Effect7	
	41-45	Effect8	
	46-50	Effect9	
	51-55	Effect10	
	56-60	Effect11	
	61-65	Effect12	
	66-70	Effect13	
	71-75	Effect14	
	76-80	Effect15	
	81-85	Effect16	
	86-90	Effect17	
	91-95	Effect18	
	96-100	Effect19	
	101-105	Effect20	
	106-110	Effect21	
	111-115	Effect22	
116-120	Effect23		
121-125	Effect24		

Channel	DMX		Percentage	Function
	126-130		Effect25	
	131-135		Effect26	
	136-140		Effect27	
	141-145		Effect28	
	146-150		Effect29	
	151-155		Effect30	
	156-160		Effect31	
	161-165		Effect32	
	166-170		Effect33	
	171-175		Effect34	
	176-180		Effect35	
	181-185		Effect36	
	186-190		Effect37	
	191-195		Effect38	
	196-200		Effect39	
	201-205		Effect40	
	206-210		Effect41	
	211-215		Effect42	
	216-220		Effect43	
	211-255		NO Function	
9	0-255		Effect Speed	

channel (Extended 45CH)

Channel	DMX	Percentage	Function
1	0-255	0-100	Dimmer
2	0-255	0-100	Shutter
3	0-255	0-100	Red 1
4	0-255	0-100	Green 1
5	0-255	0-100	Blue 1
6	0-255	0-100	White 1
7	0-255	0-100	Red 2
8	0-255	0-100	Green 2
9	0-255	0-100	Blue 2
10	0-255	0-100	White 2
11	0-255	0-100	Red 3
12	0-255	0-100	Green 3
13	0-255	0-100	Blue 3
14	0-255	0-100	White 3
15	0-255	0-100	Red 4
16	0-255	0-100	Green 4
17	0-255	0-100	Blue 4
18	0-255	0-100	White 4
19	0-255	0-100	Red 5
20	0-255	0-100	Green 5
21	0-255	0-100	Blue 5
22	0-255	0-100	White 5
23	0-255	0-100	Red 6
24	0-255	0-100	Green 6
25	0-255	0-100	Blue 6
26	0-255	0-100	White 6
27	0-255	0-100	Red 7
28	0-255	0-100	Green 7
29	0-255	0-100	Blue 7
30	0-255	0-100	White 7
31	0-255	0-100	Red 8
32	0-255	0-100	Green 8

Channel	DMX	Percentage	Function
33	0-255	0-100	Blue 8
34	0-255	0-100	White 8
35	0-255	0-100	Red 9
36	0-255	0-100	Green 9
37	0-255	0-100	Blue 9
38	0-255	0-100	White 9
39	0-255	0-100	Red 10
40	0-255	0-100	Green 10
41	0-255	0-100	Blue 10
42	0-255	0-100	White 10
43	0-255	0-100	Macro
44	Effects		
	0-5		No Function
	6-10		Effect1
	11-15		Effect2
	16-20		Effect3
	21-25		Effect4
	26-30		Effect5
	31-35		Effect6
	36-40		Effect7
	41-45		Effect8
	46-50		Effect9
	51-55		Effect10
	56-60		Effect11
	61-65		Effect12
	66-70		Effect13
	71-75		Effect14
	76-80		Effect15
	81-85		Effect16
	86-90		Effect17
91-95		Effect18	
96-100		Effect19	

Channel	DMX	Percentage	Function
44	101-105	0-100	Effect20
	106-110	0-100	Effect21
	111-115	0-100	Effect20
	116-120	0-100	Effect23
	121-125	0-100	Effect24
	126-130	0-100	Effect25
	131-135	0-100	Effect26
	136-140	0-100	Effect27
	141-145	0-100	Effect28
	146-150	0-100	Effect29
	151-155	0-100	Effect30
	156-160		Effect31
	161-165		Effect32
	166-170		Effect33
	171-175		Effect34
	176-180		Effect35
	181-185		Effect36
	186-190		Effect37
	191-195		Effect38
	196-200		Effect39
201-205		Effect40	
206-210		Effect41	
211-215		Effect42	
216-220		Effect43	
221-255		No Function	
45	0-255		Effects Speed

channel (25CH)

Channel	DMX	Percentage	Function
1	0-255	Dimmer	
2	0-255	Shutter	
3	0-255	C1	
4	0-255	C2	
5	0-255	C3	
6	0-255	C4	
7	0-255	C5	
8	0-255	C6	
9	0-255	C7	
10	0-255	C8	
11	0-255	C9	
12	0-255	C10	
13	0-255	W1	
14	0-255	W2	
15	0-255	W3	
16	0-255	W4	
17	0-255	W5	
18	0-255	W6	
19	0-255	W7	
20	0-255	W8	
21	0-255	W9	
22	0-255	W10	
23	0-255	Macro	
24	0-255	Effect	
	0-5	NO Function	
	6-10	Effect1	
	11-15	Effect2	
	16-20	Effect3	
	21-25	Effect4	
	26-30	Effect5	
	31-35	Effect6	
	36-40	Effect7	
	41-45	Effect8	
	46-50	Effect9	
	51-55	Effect10	
	56-60	Effect11	
	61-65	Effect12	
	66-70	Effect13	
71-75	Effect14		
76-80	Effect15		

Channel	DMX		Percentage	Function
24	81-85		Effect16	
	86-90		Effect17	
	91-95		Effect18	
	96-100		Effect19	
	101-105		Effect20	
	106-110		Effect21	
	111-115		Effect22	
	116-120		Effect23	
	121-125		Effect24	
	126-130		Effect25	
	131-135		Effect26	
	136-140		Effect27	
	141-145		Effect28	
	146-150		Effect29	
	151-155		Effect30	
	156-160		Effect31	
	161-165		Effect32	
	166-170		Effect33	
	171-175		Effect34	
	176-180		Effect35	
181-185		Effect36		
186-190		Effect37		
191-195		Effect38		
196-200		Effect39		
201-205		Effect40		
206-210		Effect41		
211-215		Effect42		
216-220		Effect43		
211-255		NO Function		
25	0-255		Effect Speed	

CHANNEL (Standard18CH)

Channel	DMX	Percentage	Function
1	0-255	Dimmer	
2	0-255	Shutter	
3	0-255	Red	
4	0-255	Green	
5	0-255	Blue	
6	0-255	White	
7	0-255	C1	
8	0-255	C2	
9	0-255	C3	
10	0-255	C4	
11	0-255	C5	
12	0-255	C6	
13	0-255	C7	
14	0-255	C8	
15	0-255	C9	
16	0-255	C10	
17	0-255	Effect	
	0-5	NO Function	
	6-10	Effect1	
	11-15	Effect2	
	16-20	Effect3	
	21-25	Effect4	
	26-30	Effect5	
	31-35	Effect6	
	36-40	Effect7	
	41-45	Effect8	
	46-50	Effect9	
	51-55	Effect10	
	56-60	Effect11	
	61-65	Effect12	
	66-70	Effect13	
	71-75	Effect14	
	76-80	Effect15	
	81-85	Effect16	
	86-90	Effect17	
	91-95	Effect18	
	96-100	Effect19	
	101-105	Effect20	
	106-110	Effect21	
111-115	Effect22		
116-120	Effect23		

Channel	DMX		Percentage	Function
17				
	121-125		Effect24	
	126-130		Effect25	
	131-135		Effect26	
	136-140		Effect27	
	141-145		Effect28	
	146-150		Effect29	
	151-155		Effect30	
	156-160		Effect31	
	161-165		Effect32	
	166-170		Effect33	
	171-175		Effect34	
	176-180		Effect35	
	181-185		Effect36	
	186-190		Effect37	
	191-195		Effect38	
	196-200		Effect39	
201-205		Effect40		
206-210		Effect41		
211-215		Effect42		
216-220		Effect43		
211-255		NO Function		
18	0-255		Effect Speed	

CHANNEL (40CH)

Channel	DMX	Percentage	function	note
1	0-255		Red	
2	0-255		Green	
3	0-255		Blue	
4	0-255		White	
5	0-255		Red	
6	0-255		Green	
7	0-255		Blue	
8	0-255		White	
9	0-255		Red	
10	0-255		Green	
11	0-255		Blue	
12	0-255		White	
13	0-255		Red	
14	0-255		Green	
15	0-255		Blue	
16	0-255		White	
17	0-255		Red	
18	0-255		Green	
19	0-255		Blue	
20	0-255		White	
21	0-255		Red	
22	0-255		Green	
23	0-255		Blue	
24	0-255		White	
25	0-255		Red	
26	0-255		Green	
27	0-255		Blue	
28	0-255		White	
29	0-255		Red	
30	0-255		Green	
31	0-255		Blue	
32	0-255		White	
33	0-255		Red	
34	0-255		Green	
35	0-255		Blue	
36	0-255		White	
37	0-255		Red	
38	0-255		Green	
39	0-255		Blue	
40	0-255		White	