

LIGHT SKY[®]

FLY DRAGON LIGHTING EQUIPMENT CO.,LTD



LIGHT SKY[®]

Tel:0086-20-61828288

Fax:0086-20-61828188 Pc:510800

Web:www.lightsky.com.cn

E-mail: flydragon@lightsky.com.cn

asia@lightsky.com.cn

india@lightsky.com.cn

europa@lightsky.com.cn

latinamerica@lightsky.com.cn

middle-east@lightsky.com.cn

american@lightsky.com.cn

Address: No. 43, Yunfeng Road, Xiuquan Street,
Huadu District, Guangzhou, China



LIGHT SKY[®]



PL61W3 USER MANUAL

Please read these user manual carefully before use

CHANNEL FUNCTION

| CHANNEL | DMX VALUE | % | FUNCTION |
|----------|-----------------|--------|---------------------------------------|
| 1 | 0-255 | 0-100 | Dimmer |
| 2 | 0-255 | 0-100 | CCT |
| 3 | Shutter | | |
| | 0-9 | 0-3 | No Function |
| | 10-49 | 4-19 | Slow closing, Fast opening, Slow→Fast |
| | 50-89 | 20-34 | Fast closing, Slow opening, Slow→Fast |
| | 90-119 | 35-46 | Slow closing, Slow opening, Slow→Fast |
| | 120-179 | 47-70 | Random strbe, Slow→Fast |
| | 180-249 | 71-98 | Synchronous strbe, Slow→Fast |
| | 250-255 | 99-100 | NO Function |
| 4 | Zoom | | |
| | 0 | 0 | |
| | 255 | 100 | Zoom |
| 5 | Function | | |
| | 0-128 | 0-50 | NO Function |
| | 129-255 | 51-100 | Reset |